


Darcy Friction Factor for Pipe Flow

Reynolds Number



Reynolds Number $Re = \frac{\rho V D}{\mu} = \frac{V D}{\nu}$